
MOTORVAC
TECHNOLOGIES INC.

INDUSTRIAL
TRANSTECH
Transmission Service System

Operator Manual


Table of Contents

| | |
|--|------------------------------|
| Introduction | Error! Bookmark not defined. |
| Overview | Error! Bookmark not defined. |
| System Features and Functions | 1-1 |
| Control Panel Features and Functions | 1-1 |
| Left View | 1-3 |
| Right View..... | 1-4 |
| Theory of Operation..... | 1-5 |
| Safety Information | 2-1 |
| Before You Begin | 3-1 |
| First Time Operation | 3-1 |
| Transmission Service Procedure | 4-1 |
| Troubleshooting and Additional Help | 5-1 |
| Appendix A - Maintenance | A-1 |
| Maintenance Procedures | A-1 |
| Cleaning the Unit's Filter Screen | A-1 |
| Maintenance Record..... | A-3 |
| Appendix B - System Accessories | B-1 |
| Adapter Kit | B-1 |
| Appendix C - Parts | C-1 |
| External Parts | C-1 |
| Ordering Parts..... | C-1 |

System Features and Functions


The front of the INDUSTRIAL TRANSTECH cabinet contains the control panel, the fluid fill neck for adding new transmission fluid, and the fluid level windows. (See page 1-4 for complete theory of operation)

Front View - Control Panel Features and Functions




| | |
|---|---|
| A. Change Fluid button | <ul style="list-style-type: none"> Starts exchanging used fluid for new fluid / Service in progress mode. Starts the unit during the “Prime” procedure. |
| B. Drain button | <ul style="list-style-type: none"> Drains fluid from vehicle’s transmission when performing the drain pan procedure. Provides momentary drain function when the units “Complete” light is illuminated. |
| C. Low Vehicle Fluid warning light | Illuminates when: <ul style="list-style-type: none"> Vehicle transmission fluid is two quarts low. When vehicles transmission is empty at end of drain pan procedure. |
| D. Complete light | Illuminates when: <ul style="list-style-type: none"> The service procedure has been completed The stop button has been pressed & unit’s alarm is not sounding |
| E. Engine – Start /On warning light | <ul style="list-style-type: none"> Flashes when the vehicle’s engine needs to be started. Illuminated constantly when vehicle’s engine is running & the unit senses fluid pressure. |
| F. Engine - Stop/Off warning light | <ul style="list-style-type: none"> Flashes when the vehicle’s engine needs to be stopped. Illuminated constantly when the vehicle’s engine is OFF. |
| G. Fill button | <ul style="list-style-type: none"> Adds a pre-programmed amount of fluid to the transmission at beginning of service. Adds a pre-programmed amount of fluid to the transmission after the Drain procedure. Provides momentary fill function when the unit’s Complete light is illuminated. |
| H. Low Clean Fluid warning light | Illuminates when the clean fluid tank in the machine is empty / “zero” level. |
| I. Fill- Additional fluid count lights | Will illuminate according to the amount of pre-programmed fluid that will be added. |
| J. Stop button | <ul style="list-style-type: none"> Stops units pump & completely resets unit (<i>if alarm is not sounding</i>). Stops units alarm if alarm is sounding. |
| K. Empty Waste button | Empties used transmission fluid from the unit’s waste tank. |

Left View:



| | |
|---|---|
| A. Adaptor Tray | Used to store the unit's adaptors. |
| B. Output / Return Hose | Connects to the Transmission's cooling system. |
| C. Disposal Hose | Inserts into the shop's fluid recycling receptacle or into a suitable container approved for storing used transmission fluid. |
| D. Serial Number Plate | Identifies the unit's model & specific manufacturer's production number. |
| E. Tank filler neck (Not shown) | Access port to add new transmission fluid to the unit's new fluid tank. |
| F. Quick Coupler | Secures the needed service adaptors to the unit's output / return hose assemblies. |
| G. Disposal Hose Check Valve | Prevents excessive drainage from waste hose, opens automatically when EMPTY WASTE button is pushed. |

Right View:



| | |
|---|--|
| A. Output / Return Hose | Connects to the Transmission's cooling system. |
| B. External Power Harness w/ Battery Clamps | Positive + (Red) battery connection. Negative - (Black) battery connection. |
| C. Quick Coupler | Secures the needed service adaptors to the unit's output / return hose assemblies. |
| D. Adaptor Tray | Used to store the unit's service adaptors. |

Theory of Operations

Detailed descriptions of the various operations, control buttons, and indicators that make up the control panel are listed below.

OFF MODE:

- When the unit is connected to power, an alarm will sound indicating power-up. Fluid will be re-circulated to the vehicle's transmission.
- When the vehicle is started, the unit will sound an alarm indicating that fluid and pressure from the vehicle have reached the machine and it is ready for service.

CHANGE FLUID:

If pressed before draining the transmission pan (at beginning of service), the unit will automatically route the used fluid from the vehicle's transmission into the unit's WASTE tank, and supply an equal amount of new fluid from the unit's CLEAN fluid tank to the vehicle.

- **If pressed after the transmission fluid was drained using the DRAIN button,** the machine will add to the transmission the equal amount of fluid collected during the drain mode, plus the amount entered manually using the FILL button (see FILL section), once this amount is added to the transmission, an alarm will sound and the ENGINE START light will flash. At this time the technician should start the engine. Once started, the machine will automatically route the used fluid to the WASTE tank and supply new fluid into the vehicle's transmission.

Note: Fluid level in the transmission may vary during service. Level will be adjusted automatically at end of service.

- **If pressed and held while power is connected to unit,** the unit's computer will commence the PRIME mode. This procedure is used any time the waste tank is drained completely.

DRAIN:

- **If pressed at beginning of service,** fluid will be drained from the vehicle's transmission into the machine's WASTE tank until no fluid is received from the vehicle's transmission. An alarm and ENGINE STOP light will be activated when the transmission fluid pan is empty.
- The machine's computer will account for the amount of fluid collected in the WASTE tank during the DRAIN mode.
- **If pressed after service,** (The COMPLETE light is lit), fluid will drain only as long as the button is pressed, flow will stop when the button is released.

FILL:

- **If pressed at beginning of service,** for every time pressed the unit count ½ of a quart, a light will turn ON to indicate the amount entered (see chart in this section). The unit will automatically add the amount of fluid indicated to the overall fluid level of the transmission.

EXAMPLE: When the technician checks the transmission's fluid level before beginning the service, and the

level in the transmission is $\frac{1}{2}$ of a quart low, the FILL button should be pressed once. The light above the $\frac{1}{2}$ qt. indicator will light. This amount of fluid will automatically be added to the transmission during the service. The alternative action would be for the technician to add the correct amount of fluid manually to the transmission, before starting the service.

- **If pressed after DRAIN mode**, the unit will add the amount of fluid entered according to the lights that are lighted under the FILL button (see chart in this section).

EXAMPLE: When the transmission fluid pan is to be removed, the technician will press the DRAIN button, the unit will empty fluid until the filter cannot pull any from the pan. Once the pan is removed there will be some fluid left at the bottom of the pan, this fluid is emptied manually into the shop's recycling container. When this happens, the machine will not account for the fluid that was removed manually. The technician should calculate the amount of fluid removed manually, then press the FILL button according to the amount calculated.

- **If pressed when the COMPLETE light is ON, but the LOW CLEAN FLUID light is OFF**, First press, the pump will run continuously. Second press, $\frac{1}{2}$ qt. light will turn on, the unit will add half of a quart and stop automatically. Press three times, the 1 qt light will turn on and the unit will add one full quart and stop automatically etc,. See chart below.

FILL- ADDITIONAL FLUID COUNT LIGHTS:

First light on = $\frac{1}{2}$ qt.

Second light on = 1 qt.

First and second lights on = $1 \frac{1}{2}$ qts.

Third light on = 2 qts.

Third and first lights on = $2 \frac{1}{2}$ qts.

Third and second lights on = 3 qts.

All lights on = $3 \frac{1}{2}$ qts. / Maximum fluid added automatically.

Pressing the Fill button once more will turn all lights off.

LOW CLEAN FLUID:

- The light will be on when the CLEAN FLUID tank is empty.

COMPLETE:

- The COMPLETE light will turn on when clean fluid tank is empty or the STOP button is pressed. The unit will automatically revert to re-circulating mode.

ENGINE START/ON:

- The light will flash if the engine needs to be started to continue
- The light will be on constantly when the engine is running or if the machine's system is pressurized over 4 psi.

ENGINE STOP/OFF:

- The light will flash if the engine needs to be stopped/turned off.
- The light will be on constantly when the engine is not running.

EMPTY WASTE:

- The light will be on when the waste fluid is at/or over 4 quarts in the WASTE tank. The unit will not run unless the level in the waste tank is less than $\frac{1}{4}$ full (approximately 4 qts.).

STOP:

- Will turn off an alarm without stopping the service when sounding.
- Will stop the pump and revert the system to recirculating mode, (if no alarm is sounding).

NOTE: If the unit needs to be stopped completely while an alarm is sounding, press the STOP button TWICE. The first press will stop the alarm and the second press will stop the pump.

Safety Information and Precautions

!/\ DANGER

Vehicle exhaust gases contain Carbon Monoxide, which is a colorless and odorless lethal gas.

Only run engines in well-ventilated areas and avoid breathing exhaust gases.

Extended breathing of exhaust gases will cause serious injury or death.

!/\ WARNING

Exhaust gases, moving parts, hot surfaces are present during and after the vehicle's engine is running.

Read and understand the operator's manual before using the TRANSTECH Service system.

When using petroleum products always refer to the MSDS sheets and manufacturer's instructions for the proper procedure to handle emergency medical treatment, cleanup, handling, and storage requirements.

Improper use of the INDUSTRIAL TRANSTECH Transmission Service System or exposure to exhaust gases can cause injury.

Spilled transmission fluid on an engine can ignite.

Avoid exposure to flames, sparks, hot engine parts, and other ignition sources.

Always keep fully charge fire extinguisher nearby. The extinguisher should have a class B rating and be suitable for gasoline, chemical, and electrical fires.

Cleanup any oil spills immediately.

Dispose of contaminated cleanup material according to governing environmental laws.

Never look directly into the air induction plenum or carburetor throat when the engine is operating.

Always verify hose connections to the transmission's oil cooler lines before starting the vehicle's engine.

Explosion or flame or exposure to flammable liquid and vapors can cause injury.

Flammable liquid (transmission fluid) can splash out of reservoir when filling or when unit is being moved.

Always keep Reservoir Cap secure except when filling reservoir.

Explosion or flame can cause injury.

Transmission cooling systems may maintain residual pressure in connection lines to and from transmission and cooler radiator even after the engine has been turned off.

Wear safety goggles.

Wear chemical resistant gloves when connecting or disconnecting fitting and adapters.

Chemicals can cause harmful byproducts - do not add any chemicals to INDUSTRIAL TRANSTECH's reservoir tank.

Use only approved automatic transmission fluid.

Do not swallow or ingest any chemicals.

Use with adequate ventilation. Avoid breathing vapors.

Do not store chemicals in or on the machine (other than automatic transmission fluid).

Improper use of transmission fluid can cause injury.

Over exposure can have harmful effect on eyes, skin, respiratory system and possible unconsciousness and asphyxiation.

Improperly blocked vehicles can move.

Set the parking brake and chock the wheels.

Moving vehicles can cause injury.

Moving engine parts.

The engine cooling fan will cycle on and off depending on the coolant temperature and could operate without the engine running.

Wear safety goggles.

Always keep objects, clothing, and hands away from the cooling fans and engine parts.

Moving engine parts can cause injury.

Hot surfaces are present during and after running the engine.

Do not contact hot surfaces such as, manifolds, pipes, mufflers, catalytic converters, or radiators and hoses.

Hot surfaces can cause injury.

Catalytic converters become extremely hot.

Do not park a converter-equipped vehicle over dry grass, leaves, paper, or any other flammable material. Do not touch a catalytic converter until the engine has been off for at least 45 minutes.

Catalytic converters can cause burns.

Cracked fan blade can become airborne.

Examine fan blades for cracks. If found, do not service the vehicle.

Flying objects can cause injury.

Batteries produce explosive gases and can explode.

Wear safety goggles when working on or near batteries.

Use in a well-ventilated area.

Keep sparks and flames away from the battery and never lay tools, equipment, or other conductive objects on the battery.

When tools or equipment are connected to the battery, make sure the equipment power switch is off.

Connect the positive lead of the equipment to the positive lead battery first; connect the negative lead of the equipment to a solid ground point as far from the battery as possible.

Keep battery acid away from skin or eyes. In case of eye contact, flush with clean water for 15 minutes and get medical attention.

Battery explosion and ignited gases can cause injury.

Before You Begin

First Time Operation / Priming Procedure

NOTE

This unit has been tested with Dextron III Automatic Transmission Fluid, and is ready for service after receiving inspection of the unit.

Remember to send in your warranty card to properly register your machine.

1. Check the output/return hoses, battery connections, and all external components for damage.
2. Fill the unit's reservoir with a minimum of 20 quarts of **new transmission fluid**.
3. Connect two compatible adapters to each other, secure tightly. Attach the output/return hoses together using the proper adapters.
4. Insert the Disposal hose into the unit filler neck (or into a suitable container if the unit has been used to service a vehicle previously).
5. Attach the unit's black (-) negative battery clip to a solid ground point as far from the battery as possible, (do not connect the positive battery connector yet).
6. Press and hold CHANGE FLUID button, connect the positive power harness clamp to the vehicle's 12 volt battery, allow the unit to run until the EMPTY WASTE light begins to flash, then press STOP.
7. Press the EMPTY WASTE button, let unit run until it stops automatically.
8. Press the DRAIN button to release pressure contained within the output/return hoses.
9. Disconnect power to machine and check new transmission fluid level, add if necessary.
10. The unit is now ready to perform a service. See service instructions for procedure.

NOTE

Steps 1-9 must be performed BEFORE first time operation and/or any time the unit's reservoir is completely drained of fluid.

Transmission service procedure

Follow the steps below to connect the unit to the vehicle's transmission cooler lines.
Make sure the vehicle has at least 1/8 tank of fuel before beginning this process.

IMPORTANT

Do not perform the transmission service if the vehicle's engine oil or coolant level is low.
If necessary, add motor oil and/or coolant.

/!\ WARNING



Flammable Liquid can squirt out of pressurized lines when connecting or disconnecting.

Verify that engine and machine are both off before connecting or disconnecting cooler lines or adapters.

Wear safety goggles.

Wear chemical resistant gloves when connecting or disconnecting fittings and adapters.

Wrap a shop towel around pressure fittings and adapters when disconnecting.


Avoid exposure to flames, sparks, hot engine parts, and other ignition sources.

Explosion or flame or exposure to flammable liquid and vapors can cause injury.

1. Add the correct amount of automatic transmission fluid into the INDUSTRIAL TRANSTECH'S clean tank reservoir. See vehicle's service manual for fluid quantity.
2. Start engine, let run until it reaches operating temperature, turn engine OFF.
3. Locate and disconnect the cooler line at the easiest connection point:
 - At cooler line connection to radiator.
 - At heat exchanger.
 - At filter connection, (Side marked OUT of filter base)
 - At cooler line connecting to the transmission.

NOTE: Adapters are connected to either cooler line, "from" or "to" the radiator and/or the transmission.

4. Install the proper adapters onto the disconnected lines.
5. Connect the *FLOW DIRECTION INDICATOR LOOP* ("H" adapter) to the previously attached cooler line adapters. NOTE: The ball valve must be in the closed position. (The valve handle is at a right angle to flow.) See photo.



6. Attach the unit to the vehicle's battery by connecting the unit's red battery clip to the positive (+) battery terminal and connecting the black (-) battery clip to a solid ground point as far from the battery as possible. The ENGINE START/ON light will be flashing.

NOTE: Connect to 24 volts whenever possible.

7. *Start* the vehicle's engine. Note the direction of flow, (dirty oil) from the cooler lines (right or left side of the adapter). After determining direction of flow, rotate the valve handle 90° counterclockwise. Transmission is now in closed loop (or bypass) operation.
8. Attach the unit's hose marked "Dirty Oil" to the side of the "H" adapter that indicated flow *from* the vehicle (dirty side). Attach the hose marked "Clean Oil" to the side of the adapter that indicated flow *to* the vehicle. Once unit's lines are connected to the "H" adapter, close the "H" adapter valve handle. The ENGINE START/ON light should be ON solid.

NOTE: Transmission fluid will circulate through the unit and return to the vehicle's transmission when unit is off (bypass mode).

If no flow is indicated;

And the start-up alarm does not sound when the engine is started, or the unit does not commence service when the CHANGE FLUID button is pressed. Check filter and transmission fluid cooler for blockage.

9. Filter Change:

If the vehicle's transmission pan is to be removed, perform the following steps before removal of the transmission oil pan. If not, go to step 8.

- a) Follow steps 1-6, note fluid level in the WASTE tank, then press the Drain button, allow 10 qts. of fluid to drain if the vehicle is equipped with a "shallow" pan. Drain 12-14 qts. of fluid if the vehicle is equipped with a "deep" transmission pan.

NOTE: It is possible to drain the transmission pan through the drain plug if so equipped. If the pan is drained manually, it is necessary to add new transmission fluid manually through the normal channel, (usually the dipstick tube), before proceeding with service.

CAUTION

Letting the transmission run for an extended period of time without fluid can cause serious damage to internal components.

- b) Stop the vehicle's engine. The machine will sound an alarm and flash the LOW VEHICLE FLUID and ENGINE STOP/OFF lights.
- c) Press STOP button once to turn alarm off.
- d) Replace or clean the vehicle's transmission fluid filter, (if applicable), and reinstall the transmission's oil pan as per shops repair manual and manufacturer's recommendations.
- e) Note the approximate amount of fluid removed from the transmission's fluid pan after it was removed from the transmission.
- f) Press the unit's FILL button according to approximate amount of fluid removed from the transmission's fluid pan, (step c), Press Once = ½ qt. Twice = 1 qt *Etc.*
- g) Press CHANGE FLUID button. The unit will fill the vehicle's transmission according to the amount emptied into the unit's WASTE tank and the amount of fluid entered from step f).
- h) *Start* the vehicle's engine when the START ENGINE flashes and alarm sounds.

10. Continue with the service until all fluid has been exchanged and the unit stops automatically. Press STOP to turn off alarm.

NOTE: Quantity of fluid used per vehicle may vary depending on the condition of the fluid in the transmission of the vehicle being serviced.

11. Let engine run for one minute, then check the transmission's fluid level.

If level is low:

- a) Press and hold the FILL button for 5-10 seconds.
- b) Re-check fluid level, repeat step "a)" if necessary.

If level is high:

c) Press and hold the DRAIN button for 5-10 seconds.

d) Re-check fluid level, repeat step “ c) ” if necessary.

Stop engine and let cool off if necessary.

12. Disconnect hoses from the INDUSTRIAL TRANSTECH and connect the vehicle’s cooler lines to their original connection ports.

13. Start the engine, check cooler lines for leaks, and re-tighten as necessary.

14. Step on the foot brake firmly, then slowly shift the gear lever to Low Gear (first gear) then back to Park. Check the transmission’s fluid level, adjust if necessary.

Service tip: To minimize fluid mixture, a “Pan Drain” procedure may be performed, (without removing the transmission pan).

A) Follow steps 1-6 from this section.

Perform Filter change procedure steps: a), b), c), g), h).

C) Continue with steps 8 & 9.

Troubleshooting and Additional Help

Refer to the list below in the unlikely event that you have problems with your **INDUSTRIAL TRANSTECH Transmission Service System**.

Problem:

- 1. Unit does not power-up, no LEDs are lighted**
- 2. Unit does not sound the start-up alarm**
- 3. The start-up alarm sounds, and an intermittent alarm sounds 30-40 seconds after pressing the Change Fluid button.**
- 4. Unit stops and alarm sounds 30 - 40 seconds after pressing the Drain button**
- 5. An intermittent alarm sounds during the Transmission Service Procedure, and the ENGINE STOP light is flashing.**
- 6. The level in the transmission is 2 qts. low after service.**
- 7. New fluid is above the 2qt. line, but the LOW CLEAN FLUID light is ON.**
- 8. The unit performs poorly.**

Solution:

- Polarity is reversed on vehicle battery connection. Check connection to battery for a loose condition.
- No fluid/pressure is reaching the machine. See Transmission Service Procedure, page 4-2 steps a, b, and c. also see steps 3 and 4 of this page.
- Fluid flow is extremely slow, but enough to pressure the system to 4 psi. service ports are opened when Change Fluid is pressed, then pressure drops completely, this will trigger the alarm. Verify flow. See Transmission Service Procedure, page 4-2 steps a, b, and c. See steps 2 & 4, of this page.
- No fluid is being received in unit's WASTE tank, Check hose connections to adapters
Check adapters for a kinked condition.
Check vehicle's fluid flow. See: Transmission Service procedure, page 4-2 steps a, b and c.
See steps 2 and 3 of this page.
- The transmission fluid level is low 2 qts. press STOP button **Once**, this will stop the alarm, but not the unit's pump. Check transmission fluid level, stop engine if fluid is low enough that the dipstick does not reach to measure fluid. The unit will sound an alarm when fluid has reached the proper level, start engine and proceed with service. Check hose connections to adapters for proper connection, check adapters and hoses for a kinked condition.
- The low level switch from the WASTE tank may have become disconnected previous to starting the service. Insert unit's Drain Hose into a waste oil recycling container. Press DRAIN WASTE button. Verify that the pump stops automatically and that fluid level is still visible through the visual level window. If not, remove unit's back panel and check waste tank level switch wire connections.
- The low level switch on the new fluid tank has become disconnected. Remove unit's back panel and check the clean tank level switch wire connections.
- Check all hoses and wires for cuts or frays.
Check cabinet for dents or impact markings.
Verify that the filter screen has recently been cleaned. (Refer to the maintenance log in **Appendix A** to view dates of services performed.)

ADDITIONAL HELP

Please verify that items 1-6 above have been reviewed before calling for additional assistance.

In the unlikely event that problems persist with the unit call

Technical Support, have your model and serial numbers available before you call. Remember to send in your warranty card.

In the U.S.
(800) 841-8810

Outside the U.S.
Call your local distributor

Standard Adapter Kit

The most commonly used application are listed below; however, other applications may apply.




| PART | Qty | Application |
|---|------------|---|
|  | 1 | 064-3008 #8 X # 12 JIC NIPPLE COOLER LINE |
|  | 1 | 064-3010 #10X X 12 JIC NIPPLE COOLER LINE |
|  | 1 | 064-3012 #12 X # 12 JIC NIPPLE COOLER LINE |
|  | 1 | 064-4008 #8 JIC FEMALE COOLER LINE |
|  | 1 | 064-4010 #10 JIC FEMALE COOLER LINE |

| PART | Qty | Application |
|---|-----|--|
|  | 2 | 064-4012 #12 JIC FEMALE COOLER LINE |
|  | 1 | 064-3034 #10 JIC X 3/4" MALE PIPE HEAT EXCHANGER / FILTER BASE (Filter Side Marked OUT) |
|  | 1 | 064-4034 #12 JIC X 3/4" FEMALE PIPE HEAT EXCHANGER / FILTER BASE (Filter Side Marked OUT) |
|  | 1 | 064-3100 #12 JIC X 1" MALE PIPE HEAT EXCHANGER / FILTER BASE (Filter Side Marked OUT) |


| PART | Qty | Application |
|---|-----|--|
|  | 1 | 064-4100 #12 JIC X 1" FEMALE PIPE HEAT EXCHANGER / FILTER BASE (Filter Side Marked OUT) |
|  | 1 | 064-4021 #12 X #16, JIC REDUCING MALE UNION COOLER LINE |
|  | 1 | 064-4022 NOTE: TWO PARTS (#16 nut swivels on #12 union) #12 X #16, JIC FEMALE UNION COOLER LINE |

Optional HEAVY DUTY TRANS Adapters

The following TRANS adapters have been added to the INDUSTRIAL TRANSTECH adaptor line-up. The adapters listed are not included with any configured adapter sets & must be purchased separately from MotorVac Technologies, Inc.

| PART & NO. | APPLICATION |
|--|---|
|  <p data-bbox="266 919 667 974">Adaptor Kit - 200-</p> | <p data-bbox="906 512 1338 653">International Harvester Trucks Late Model Application Note: These three pieces are sold as a kit.</p> <p data-bbox="906 695 1325 800">064-4111 #12 X #12, SAE MALE UNION COOLER LINE</p> <p data-bbox="906 842 1289 947">064-4112 #12 SAE FEMALE to MALE COOLER LINE</p> |
|  | <p data-bbox="906 1045 1029 1077">064-3020</p> <p data-bbox="906 1119 1357 1188">#20 JIC MALE NIPPLE (Use with 064-4020 and 064-4012)</p> |
|  | <p data-bbox="906 1455 1029 1486">064-4020</p> <p data-bbox="906 1528 1305 1633">#20 JIC FEMALE ADAPTOR NOTE: TWO PARTS (#20 nut swivels on #12 union)</p> |

Optional HEAVY DUTY TRANS Adapters - Continued

| PART & NO. | APPLICATION |
|--|---|
|  <p data-bbox="94 373 292 436">064-4114 Plate (080-1201 O'Ring)</p> <p data-bbox="625 373 820 466">050-1931 Base 1 1/8" x 16 THD (080-1202 O'Ring)</p> <p data-bbox="625 751 852 823">064-4115 #12 JIC x 1/2" MPT</p> <p data-bbox="284 835 430 877">200-1033</p> | <p data-bbox="1177 388 1323 420">200-1033</p> <p data-bbox="1023 430 1469 514">545 ALLISON TRANSMISSION WITH SPIN-ON FILTER:</p> <p data-bbox="1023 567 1323 777">Baldwin.....BT230 Donaldson...P55-5570 Fleetguard....LF3342 Fram.....PH3519A Luberfiner....LFP5570 Wix.....51268</p> <p data-bbox="1023 808 1388 871">NOTE: Use hoses #064-4012 (In Standard Adaptor Kit)</p> |

Appendix C - Parts

Service Parts for the INDUSTRIAL TRANSTECH

Please refer to the part numbers below when ordering parts for the unit.

| <u>Part #</u> | <u>Description</u> |
|---------------|--|
| 010-6106 | Swivel caster (5" dia.), non-locking |
| 010-6107 | Swivel caster (5" dia.), with wheel lock |
| 011-0060 | Hose bracket, black texture |
| 010-1030 | Adapter Box |
| 100-8702 | 16oz Bottle for Adaptor Box |
| 010-6060 | Reservoir cap |
| 011-0062 | Handle, black texture |
| 020-1019 | Harness, power |
| 020-1601 | Internal Light |
| 040-0612 | Screw, Allen Head, 1/4-20 x 1/2 (Handle) |
| 040-0613 | Screw, Phillips, stainless steel 6-32 (Rear panel) |
| 040-0623 | Screw, Allen Head, 8-32 x 5/8 (Control Panel) |
| 040-1200 | Screw 5/8 php x #6 (for adapter box) |
| 040-2000 | Flat washer #6 (for adapter box) |
| 040-2200 | Threaded Standoff (for adapter box) |
| 050-3001 | Check valve, (disposal hose) |
| 060-5810 | Cap plug (handle) |
| 080-0243 | Female Quick Disconnect Couplers, 3/4", Brass |
| 200-8732 | Output/Return hose assembly |
| 200-8612 | Disposal hose assembly |
| 200-8236 | Operators Manual, Industrial Transtech |
| 200-3107 | Adapter Kit (standard) |

See Appendix B of this manual for individual adapter part numbers.

ORDERING PARTS

Parts for the unit may be ordered by calling
Customer Service, have your model and serial numbers
available:

In the U.S.
(800) 841-8810
(714) 558-4822

Outside the U.S.
Contact Your Local
Distributor